


Comfort function when unlocking the vehicle

- f Unlock car with the remote control.
Hold car key in door lock in the unlocking direction until the windows have reached the desired position.

Anti-crushing protection

If a side window is blocked during closing, it will stop and open again by about an inch.



Risk of severe personal injuries.

If the rocker switch is pressed again within 10 seconds of the window being blocked, the window will close with its full closing force.

Anti-crushing protection is disabled.

- f Once the anti-crushing protection acts to stop the window and opens it slightly, do not press the rocker switch again within 10 seconds without checking to make sure that nothing is blocking the path of the window.
The window will close with full closing force.

One-touch operation is disabled for 10 seconds after blockage of a side window.

Automatic window lowering

- f Please observe the chapter "DOORS" on Page 21.

Storing end position of the windows

If the battery is disconnected and reconnected, the windows will not be raised automatically when the door is closed.

1. Close the windows with the rocker switch once.
2. Press the rocker switch upwards again to store the end position of the windows in the control unit.