

PORSCHE
Boxster and 911
Daytime Running Lights Kit

Contents:

	Description	Quantity
1)	Wiring loom	1
2)	# 15 fuse (needed for cars without heated seats)	1

Installation:

Step 1: Turn off vehicle

Step 2: Insert remove fuse panel cover found in the driver's side foot well

Step 3: Remove fuses A6 and A9 (A6 will not be present if your car does not have heated seats)

Step 4: Slide fuses into Wiring loom and place back into fuse box with the metal loom connector on the bottom. *** It is very important to place the fuses in with metal on the bottom**

Step5: Bend the wire to the connectors to the right so that they lay flat and wont get caught by removing the cover

Step6: Replace the fuse cover

Your done! The lights on your Porsche will turn on with the engine from now on. I hope you enjoy your new Daytime Running Lights, however if you do not you may remove the wiring loom and the car will go back to normal operation.

Thank you for your business

(Page 2 contains visuals)