



## Porsche 997 Carbon Fiber Headlight Switch Surround Install Instructions

### Tools Required

<p><b>T-20 Torx bit</b></p>	
-----------------------------	--



### Installation Steps

Step	Instructions	Photo
1	Press firmly on the headlight switch so that it moves inwards.	
2	While pressing firmly on the switch, turn the switch to the right as shown.	

# M·ACARBON

## CARBON FIBER

PORSCHE - FERRARI - LAMBORGHINI

<p>3</p>	<p>Then, pull firmly on the switch and it will slide out as shown. Disconnect the wiring from the headlight switch.</p>	
<p>4</p>	<p>Remove the three Torx screws that secure the headlight switch surround to the dash. After removing the screws, the surround can be pulled out from the dash.</p> <p>Take this opportunity to clean the dash around the surround.</p>	
<p>5</p>	<p>Put the carbon fiber headlight switch surround into the dash and screw in the four Torx screws. Connect the wiring to the headlight switch and then push the switch into the surround. Making sure that all the clips line up. Turning on your headlights will never be the same again with this beautiful piece sitting there!</p>	