

Fault code 53

Driver's side airbag

Diagnostic conditions

- Ignition on

Possible cause of fault

- ◆ Wrong driver's airbag sensor is installed

Affected terminals

Terminals 5, 6 and 20

Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
3	◆ Replace driver's airbag sensor	→ End	