



**Fog lights** in addition to parking lights or low beam:

Pull switch to first click.

Indicator light on.

The fog lights will go out automatically when the high beams are switched on.



**Rear fog light** in addition to the fog lights:

Pull switch to second click.

Indicator light on.

If the ignition key is withdrawn and the door is opened while the lights (not the parking light or Welcome Home lighting) are on, a **chime** warns of possible battery discharge.

**In some countries, differences are possible due to provisions of law.**

#### Note on operation

Further individual light functions (e.g. daytime driving lights) are available in vehicles with the Sport Chrono package.

Please observe the chapter "Individual Memory" in the separate PCM operating instructions.

## Welcome Home Lighting

### Switching on

f Move light switch to the HOME position.

For improved visibility and security when you get in and out of the car, the fog lights and the tail lights remain on for a certain period of time:

- **When you get out of the car**, the lights are turned on for approx. 30 seconds after the door is opened. The off-delay time resumes when the vehicle is locked.

On vehicles with the Sport Chrono package, the PCM can be used to set the off-delay time.

This setting also changes the lighting period for unlocking the vehicle.

Please observe the chapter "Individual Memory" in the separate PCM operating instructions.

- The lights are turned on for approx. 30 seconds **when the vehicle is unlocked**.

The lights go out if the ignition is switched on or when leaving the Welcome Home lighting.



### Light Switch

● Lights switched off

### HOME Welcome Home Function

≡DC≡ **Parking lights**, side marker lights, license plate light, instrument illumination

≡D **Low beam, high beam**  
Only with ignition on