


Emission Warranty

The emission control systems installed to vehicles for certain markets are covered by a separate warranty. A statement of the provisions is given in the Warranty section of this Owner's Guide. **You are advised to familiarise yourself with all warranty conditions at the earliest opportunity after taking delivery of your car.**

Vehicle Jacking

If this vehicle is to be raised using a vehicle jack ensure the following jacking points are use.

Do not raise the vehicle by placing a vehicle jack under the suspension arms.



⚠ Warning ⚠
Ensure that no persons are in the vehicle before jacking commences.

⚠ Warning ⚠
Ensure that the handbrake is set and that the vehicle is in 1st Gear.

⚠ Warning ⚠
Ensure that the vehicle is parked on firm and level ground to ensure a secure base for the jack.