FOR CAR USE ONLY/NUR FÜR AUTOMOBIL GEBRAUCH/POUR APPLICATION AUTOMOBILE UNIQUEMENT/PARA USO EN AUTOMÓVILES/SOLO PER L'UTILIZZO IN AUTOMOBILE/ENDAST FÖR BILBRUK/ALLEEN VOOR GEBRUIK IN DE AUTO/ТОЛЬКО ДЛЯ ИСПОЛЬЗОВАНИЯ В АВТОМОБИЛЯХ/DO UŻYCIA TYLKO W SAMOCHODZIE



8-INCH ADVANCED NAVI STATION X802D-U

7-INCH ADVANCED NAVI STATION INE-W710D

7-INCH MONITOR RECEIVER iLX-702D

- INSTALLATION MANUAL
- INSTALLATIONSANLEITUNG
- GUIDE D'INSTALLATION
- MANUAL DE INSTALACIÓN
- MANUALE DI INSTALLAZIONE
- INSTALLATIONSHANDBOK
- INSTALLATIEHANDLEIDING
- РУКОВОДСТВО ПО УСТАНОВКЕ
- INSTRUKCJA MONTAŻU

ALPINE ELECTRONICS MARKETING, INC.

1-7, Yukigaya-Otsukamachi, Ota-ku, Tokyo 145-0067, JAPAN Phone: 03-5499-4531

ALPINE ELECTRONICS OF AMERICA, INC.

19145 Gramercy Place, Torrance, California 90501, U.S.A. Phone 1-800-ALPINE-1 (1-800-257-4631)

ALPINE ELECTRONICS OF AUSTRALIA PTY. LTD.

161-165 Princes Highway, Hallam Victoria 3803, Australia Phone 03-8787-1200

ALPINE ELECTRONICS GmbH

Wilhelm-Wagenfeld-Str. 1-3, 80807 München, Germany Phone 089-32 42 640

ALPINE ELECTRONICS OF U.K. LTD.

Alpine House Fletchamstead Highway, Coventry CV4 9TW, U.K. www.alpine.co.uk

ALPINE ELECTRONICS France S.A.R.L.

184 allée des Erables CS 52016 – Villepinte 95 945 Roissy CDG cedex FRANCE Phone: + 33(0)1 48 63 89 89

ALPINE ITALIA S.p.A.

Viale Cristoforo Colombo 8, 20090 Trezzano sul Naviglio MI, Italy Phone +39 02 484781

ALPINE ELECTRONICS DE ESPAÑA, S.A.

Portal de Gamarra 36, Pabellón, 32 01013 Vitoria (Alava)-APDO 133, Spain Phone 945-283588 ΕN

DE

FR

ES

IT

SE

NL

RU

ΡL

Contents

WARNING	2
CAUTION	2
Precautions	3
Accessory List	3
Installation	3
Caution concerning the installation	
location	3
Mounting the GPS Antenna inside the	
vehicle	3
Mounting the Microphone	4
Installation example using the Original	
Mounting Bracket	4
Connections	5
If an ACC power supply is not available	8
System Example	9

! WARNING

This symbol means important instructions. Failure to heed them can result in serious injury or death.

DO NOT DISASSEMBLE OR ALTER.

Doing so may result in an accident, fire or electric shock.

KEEP SMALL OBJECTS SUCH AS SCREWS OUT OF THE REACH OF CHILDREN.

Swallowing them may result in serious injury. If swallowed, consult a physician immediately.

USE THE CORRECT AMPERE RATING WHEN REPLACING FUSES.

Failure to do so may result in fire or electric shock.

DO NOT BLOCK VENTS OR RADIATOR PANELS.

Doing so may cause heat to build up inside and may result in fire.

USE THIS PRODUCT FOR MOBILE 12V APPLICATIONS.

Use for other than its designed application may result in fire, electric shock or other injury.

MAKE THE CORRECT CONNECTIONS.

Failure to make the proper connections may result in fire or product damage.

USE ONLY IN CARS WITH A 12 VOLT NEGATIVE GROUND.

(Check with your dealer if you are not sure.) Failure to do so may result in fire, etc.

BEFORE WIRING, DISCONNECT THE CABLE FROM THE NEGATIVE BATTERY TERMINAL.

Failure to do so may result in electric shock or injury due to electrical shorts.

DO NOT ALLOW CABLES TO BECOME ENTANGLED IN SURROUNDING OBJECTS.

Arrange wiring and cables in compliance with the manual to prevent obstructions when driving. Cables or wiring that obstruct or hang up on places such as the steering wheel, shift lever, brake pedals, etc. can be extremely hazardous.

DO NOT SPLICE INTO ELECTRICAL CABLES.

Never cut away cable insulation to supply power to other equipment. Doing so will exceed the current carrying capacity of the wire and result in fire or electric shock.

DO NOT DAMAGE PIPE OR WIRING WHEN DRILLING HOLES.

When drilling holes in the chassis for installation, take precautions so as not to contact, damage or obstruct pipes, fuel lines, tanks or electrical wiring. Failure to take such precautions may result in fire.

DO NOT USE BOLTS OR NUTS IN THE BRAKE OR STEERING SYSTEMS TO MAKE GROUND CONNECTIONS.

Bolts or nuts used for the brake or steering systems (or any other safety-related system), or tanks should NEVER be used for installations or ground connections. Using such parts could disable control of the vehicle and cause fire etc.

DO NOT INSTALL IN LOCATIONS WHICH MIGHT HINDER VEHICLE OPERATION, SUCH AS THE STEERING WHEEL OR SHIFT LEVER.

Doing so may obstruct forward vision or hamper movement etc. and results in serious accident.

DO NOT INSTALL THE MONITOR NEAR THE PASSENGER SEAT AIR RAG.

If the unit is not installed correctly the air bag may not function correctly and when triggered the air bag may cause the monitor to spring upwards causing an accident and injuries.



CAUTION

This symbol means important instructions. Failure to heed them can result in injury or material property damage.

HAVE THE WIRING AND INSTALLATION DONE BY EXPERTS.

The wiring and installation of this unit requires special technical skill and experience. To ensure safety, always contact the dealer where you purchased this product to have the work done.

USE SPECIFIED ACCESSORY PARTS AND INSTALL THEM SECURELY.

Be sure to use only the specified accessory parts. Use of other than designated parts may damage this unit internally or may not securely install the unit in place. This may cause parts to become loose resulting in hazards or product failure.

ARRANGE THE WIRING SO IT IS NOT CRIMPED OR PINCHED BY A SHARP METAL EDGE.

Route the cables and wiring away from moving parts (like the seat rails) or sharp or pointed edges. This will prevent crimping and damage to the wiring. If wiring passes through a hole in metal, use a rubber grommet to prevent the wire's insulation from being cut by the metal edge of the hole.

DO NOT INSTALL IN LOCATIONS WITH HIGH MOISTURE OR DUST.

Avoid installing the unit in locations with high incidence of moisture or dust. Moisture or dust that penetrates into this unit may result in product failure.

Precautions

- Be sure to disconnect the cable from the (-) battery post before installing your unit. This will reduce any chance of damage to the unit in case of a short-circuit.
- Be sure to connect the colour coded leads according to the diagram. Incorrect connections may cause the unit to malfunction or damage to the vehicle's electrical system.
- When making connections to the vehicle's electrical system, be aware of the factory installed components (e.g. on-board computer). Do not tap into these leads to provide power for this unit. When connecting the unit to the fuse box, make sure the fuse for the intended circuit of the unit has the appropriate amperage. When in doubt, consult your Alpine dealer.
- The unit uses female RCA-type jacks for connection to other units (e.g. amplifier) having RCA connectors. You may need an adaptor to connect other units. If so, please contact your authorized Alpine dealer for assistance.
- Be sure to connect the speaker (-) leads to the speaker (-) terminal. Never connect left and right channel speaker cables to each other or to the vehicle body.

Accessory List

•	X802D-U, INE-W710D or iLX-702D	1
•	Power cable	1
•	GPS Antenna	1
•	Antenna mounting plate	1
	Cable clamp for antenna	
•	USB extension cable	1
•	PRE OUT cable	1
•	Microphone	1
	CAN I/F cable	
	W.REMOTE cable	
	Face plate (INE-W710D/iLX-702D only)	1
	HDMI Fixation Bracket	
	Flush head screw (M5×8)	4
	Screw (M5×8)	
	Owner's Manual	

Installation


X802D-U user

To install the X802D-U, refer to the manual in the separately purchased installation kit for each car type.

Caution

Do not block the unit's fan, thus preventing air circulation. If blocked, heat will accumulate inside the unit and may cause a fire.

<example>




Rear of the Unit

Caution concerning the installation location


Angle of installation

Install at an angle between horizontal and 30° . Note that installing at an angle outside of this range will result in a loss of performance and possibly damage.



Mounting the GPS Antenna inside the vehicle

- 1 Clean the mounting location.
- **2** Put on the GPS Antenna mounting plate.
- 3 Mount the GPS Antenna.




- Do not mount the GPS Antenna inside the centre console.
 - Mount the GPS Antenna on a flat plane of the dash board or rear trav.
 - Make sure the GPS Antenna is not covered (obstructed) by any metallic surface or object.
- If the GPS Antenna is mounted near the unit, the reception becomes poor, and the location of your vehicle may not be displayed correctly.
 - Mount the GPS Antenna far away enough from the unit.
 - Bundle the GPS Antenna cable away from the rear of the unit.
- Some thermal reflection type or thermal absorption type glass may interrupt high frequency waves. If reception is poor with the antenna installed inside the car, try to mount the antenna outside the car.

Mounting the Microphone

For safe use, make sure of the following:


- · Location is stable and firm.
- Driver's view and operations are not obstructed.
- Microphone is located where the driver's voice can be easily picked up (for example, on the sun visor).

When you speak into the microphone, you should not have to change your driving posture. This may cause a distraction, taking your attention away from safely driving your vehicle. Carefully consider direction and distance while mounting the microphone. Confirm that the driver's voice can be easily picked up at the selected location.



Installation example using the Original Mounting Bracket

Mount the original mounting bracket to the unit using the supplied screws.




- * To securely connect the ground lead, use an already installed screw on a metal part of the vehicle (marked (★)) or a clean, bare metal spot on the vehicle's chassis.
- 2 Connect all other leads of the unit according to details described in the "Connections" (page 5).
- **3** Mounting the unit in a car.
- Fix the cables carefully. Do not damage them by tucking them into movable parts, such as a seat rail, or by locating them against sharp or pointed edges.


Note on using HDMI Connection Cables

When using HDMI connection cables, secure the cables to the HDMI Terminals with the supplied HDMI Fixation Bracket.

- Slide the HDMI Fixation Bracket into the grooves (A).
- 2 Secure it with the screw (B).



Connections



(1) Radio Antenna Receptacle

② ISO/JASO Antenna Adapter (sold separately) ISO/JASO Antenna Adapter may be required, depending on the vehicle.

3 Speed Sensor Lead (Green/White)

Improper connection of the speed pulse line may cause important safety features of the vehicle to fail (such as the brakes or air bags). Such failures may result in an accident and loss of life. We strongly recommend that the installation be performed by a trained, authorized Alpine dealer.

4 Direct CAMERA Input Connector

Use when the optional direct camera is connected.

(5) CAN Interface Connector

To CAN Interface box

6 AUX Input Connector

Input lead for AUX video/audio signal.

 A separately sold AV/RCA interface cable (4-pole mini AV plug to 3-RCA) is required. For details on using an AV/RCA interface cable (4-pole mini AV plug to 3-RCA), see "Usable AV/RCA Interface Cable (4-pole mini AV plug to 3-RCA)" (page 7).

(7) Remote Turn-On Lead (Blue/White)

Connect this lead to the remote turn-on lead of your amplifier or signal processor.

8 Reverse Lead (Orange/White)

Connect to the plus side of the car's reverse lights. These lights illuminate when the transmission is shifted into reverse (R). With this lead properly wired, the video picture automatically switches to the rear camera whenever the car is put into reverse (R).

9 Parking Brake Lead (Yellow/Blue)

Connect this lead to the power supply side of parking brake switch to transmit the parking brake status signals to the unit.

10 ISO Power Supply Connector

11) Switched Power Lead (Ignition) (Red)

Connect this lead to an open terminal on the vehicle's fuse box or another unused power source that provides (+) 12V only when the ignition is turned on or in the accessory position.

(12) Ground Lead (Black)

Connect this lead to a good chassis ground on the vehicle. Make sure the connection is made to bare metal and is securely fastened using the sheet metal screw provided.

(13) Power Antenna Lead (Blue)

Connect this lead to the +B terminal of your power antenna, if applicable.

 This lead should be used only for controlling the vehicle's power antenna. Do not use this lead to turn on an amplifier or a signal processor, etc.

(14) Battery Lead (Yellow)

Connect this lead to the positive (+) post of the vehicle's battery.

- (15) Fuse Holder (15A)
- 16 ISO Connector (Speaker Output)
- 17) Left Rear (+) Speaker Output Lead (Green)
- 18 Left Rear (–) Speaker Output Lead (Green/Black)
- 19 Left Front (+) Speaker Output Lead (White)
- 20 Left Front (–) Speaker Output Lead (White/Black)
- 21 Right Front (-) Speaker Output Lead (Grey/Black)
- Right Front (+) Speaker Output Lead (Grey)
- 23 Right Rear (-) Speaker Output Lead (Violet/Black)
- 24 Right Rear (+) Speaker Output Lead (Violet)

② Remote Control Output Lead (Brown) (For DVD Player DVE-5300)

Connect this lead to the remote control input lead. This lead outputs the controlling signals from the remote control.

Remote Control Output Lead (Brown) (For Rear Monitor) Connect this lead to the remote control input lead. This lead outputs the controlling signals from the remote control.

27 Remote Control Input Lead (Brown/White)

Connect the external Alpine product to the remote control output lead.

28 Remote Control Output Lead (Brown)

Connect this lead to the remote control input lead. This lead outputs the controlling signals from the remote control.

② DVD Control Input Lead (Red/White) (For DVD Player DVE-5300)

Connect the DVD Player DVE-5300 to the remote control output lead.

30 Steering Remote Control Interface Connector

To steering remote control interface box.

For details about connections, consult your nearest Alpine dealer.

31 MIC Input Connector

To microphone (Included)

 When using the included microphone, set Microphone Select to "Add-on." For details, refer to "Setting the Microphone Select" in the OWNER'S MANUAL (CD-ROM).

32 Subwoofer RCA Connectors

RED is right and WHITE is left.

33 Front Output RCA Connectors

Can be used as Front Output RCA Connectors. RED is right and WHITE is left.

34 Rear Output RCA Connectors

Can be used as Rear Output RCA Connectors. RED is right and WHITE is left.

35 GPS Antenna Receptacle

Connect to GPS antenna (Included).

36 CAN I/F Connector

37 USB Connector

To USB flash drive, iPod/iPhone or Android smartphone.

38 HDMI Input Connector


- 39 HDMI Output Connector
- 40 Power Supply Connector
- **41) W.REMOTE Connector**
- (42) PRE OUT Connector

43 DAB Antenna Connector

To DAB Antenna (sold separately).

Usable AV/RCA Interface Cable (4-pole mini AV plug to


Wiring convention of this system is as follows;



 Configuration commercially available 4-pole mini AV plugs is not standardised.

If an ACC power supply is not available

Connection Diagram of SPST Switch (sold separately)




- If your vehicle has no ACC power supply, add an SPST (single-pole, single-throw) switch (sold separately) and fuse (sold separately).
- The diagram and the fuse amperage shown above are in the case when the unit is used individually.
- If the switched power (ignition) lead of the unit is connected directly to the positive (+) post of the vehicle's battery, the unit draws some current (several hundred milliamperes) even when its switch is placed in the OFF position, and the battery may be discharged.

To prevent external noise from entering the audio system.

- Locate the unit and route the leads at least 10 cm away from the car harness.
- Keep the battery power leads as far away from other leads as possible.
- Connect the ground lead securely to a bare metal spot (remove any paint, dirt or grease if necessary) of the car chassis.
- If you add an optional noise suppressor, connect it as far away from the unit as possible. Your Alpine dealer carries various noise suppressors, contact them for further information.
- · Your Alpine dealer knows best about noise prevention measures so consult your dealer for further information.


System Example

Connection of an iPod/iPhone




• Do not leave an iPod/iPhone in a vehicle for a long time. Heat and humidity may damage the iPod/iPhone, and you may not be able to play it again.

Connection of a Flash Drive




• Do not leave a flash drive in a vehicle for a long time. Heat and humidity may damage the flash drive.

Connection of an HDMI Device (iPhone with a Lightning connector)




- * When connecting an HDMI connection cable, be sure to secure it using the supplied HDMI Fixation Bracket. For details on how to secure it, see "Note on using HDMI Connection Cables" (page 4).
- Set the HDMI Setup to "HDMI." For details, refer to "HDMI Setup" in the OWNER'S MANUAL (CD-ROM).

Connection of an HDMI Device (Android device)



- A connection kit or adapter kit suitable for the type of terminal on the connecting device is required.
- Set the HDMI Setup to "HDMI." For details, refer to "HDMI Setup" in the OWNER'S MANUAL (CD-ROM).
- * When connecting an HDMI connection cable, be sure to secure it using the supplied HDMI Fixation Bracket. For details on how to secure it, see "Note on using HDMI Connection Cables" (page 4).

Connection of a DVE-5300 and a Rear Monitor with HDMI support




- ② Remote Control Output Lead (Brown) (For DVD Plyer DVE-5300)
- Remote Control Input Lead (Brown/White) (For Rear Monitor)
- 26 Remote Control Output Lead (Brown) (For Rear Monitor)
- ② DVD Control Input Lead (Red/White) (For DVD Player DVE-5300)

^{*} When connecting an HDMI connection cable, be sure to secure it using the supplied HDMI Fixation Bracket. For details on how to secure it, see "Note on using HDMI Connection Cables" (page 4).

[•] Set the HDMI Setup to "DVD." For details, refer to "HDMI Setup" in the OWNER'S MANUAL (CD-ROM).


Connection of a Mobile Digital TV Receiver or USB Player



- **6** AUX Input Connector
- 28 Remote Control Output Lead (Brown)

- AV/RCA Interface Cable (4-pole mini AV plug to 3-RCA) (sold separately)
- 2 RCA Extension Cable (sold separately)
- For details on using an AV/RCA interface cable (4-pole mini AV plug to 3-RCA), see "Usable AV/RCA Interface Cable (4-pole mini AV plug to 3-RCA)" (page 7).
- Set the AUX Name to "DVB-T" or "USB Player." For details, refer to "Setting the Auxiliary (AUX) Name" in the OWNER'S MANUAL (CD-ROM).


Connection of an External Device



6 AUX Input Connector

- AV/RCA Interface Cable (4-pole mini AV plug to 3-RCA) (sold separately)
- RCA Extension Cable (sold separately)
- You can change the name of an external device. For details, refer to "Setting the Auxiliary (AUX) Name" in the OWNER'S MANUAL (CD-ROM).
- For details on using an AV/RCA interface cable (4-pole mini AV plug to 3-RCA), see "Usable AV/RCA Interface Cable (4-pole mini AV plug to 3-RCA)" (page 7).

Connection of an External Amplifier




7 Remote Turn-On Lead (Blue/White)

2 RCA Extension Cable (sold separately)

- 32 Subwoofer RCA Connectors
- 33 Front Output RCA Connectors
- **34** Rear Output RCA Connectors

Connection of a Rearview camera




4 Direct CAMERA Input Connector

8 Reverse Lead (Orange/White)

• Set the Camera Select to "Rear." For details, refer to "Setting the Camera Input" in the OWNER'S MANUAL (CD-ROM).

Connection of a Frontview camera



4 Direct CAMERA Input Connector

• Set the Camera Select to "Front." For details, refer to "Setting the Camera Input" in the OWNER'S MANUAL (CD-ROM).